

RAINBOW3ALL





CLASS II

Ce produit contient une source lumineuse de classe d'efficacité énergétique :
This product contains a light source with energy efficiency class :
Este producto contiene una fuente luminosa con una clase de eficiencia energética de :
Dit product bevat een lichtbron met een energie-efficiëntieklasse van :



Points de collecte sur www.quefairedemesdechets.fr



Caractéristiques techniques / Características técnicas / Technical information / Caratteristiche tecniche

Référence / Reference / Referencia / Referentie	BL000122/BL000123
Tension nominale / Voltage / Tension nominal	230V
Puissance / Power / Potencia / Stroom	30W
Type de connexion / Type of connexion / Tipo de conexión	Sur Adaptateur Rail 3 allumages
Indice de protection / Ingress protection / Indice de protección	IP20
Type de source / Type of source / Tipo de fuente / Lichtbron	COB
Flux lumineux / Lumen output / Flujo luminoso nominal	2300 lm
Durée de vie / Lifetime / Vida útil nominal / Schoeffleven	L70 : 50000 h
IRC / CRI / IRC	>90
Température de couleur / Color temperature / Temperatura de color	2700K / 6500K / AUTO-RGB
Angle de diffusion / Beam angle / Angulo de haz luminoso	60°
Gradation / Dimming / Regulacion / Dimmen	Triac
Recouvrable / Recoverable / Recuperable / Terugwinbaar	Non concerné



FR L'installation doit être réalisée par un professionnel qualifié
Veuillez couper l'alimentation générale afin d'éviter les risques d'électrocutions
Veuillez vous assurer de la bonne tension du réseau



SP La instalación debe ser realizada por un profesional cualificado.
Desconecte la alimentación eléctrica para evitar el riesgo de descarga eléctrica.
Asegúrese de que la tensión de red es correcta



EN Installation and maintenance must be performed by qualified person
Please make sure to turn the power off before installation
Please make sure the lamp is working with the correct input voltage




NL De installatie moet worden uitgevoerd door een gekwalificeerde vakman.
Schakel de netvoeding uit om het risico op elektrische schokken te vermijden.
Controleer of de netspanning juist is




Le Rainbow est équipé d'une connectivité Bluetooth. Grâce à l'application *Caimeta*, disponible sur iOS et Android, vous pourrez accéder à différents réglages et configurations du luminaire. Vous trouverez les différentes possibilités et les détails en téléchargeant le manuel complet sur le site beledpro.com.


The Rainbow is equipped with Bluetooth connectivity. With the *Caimeta* app, available on iOS and Android, you can access various settings and configurations for the light fixture. You can find all the available options and details by downloading the full manual on the beledpro.com website.






Appuyez pendant 5 secondes pour restaurer les paramètres
Long press for 5 seconds to restore to factory settings





Reset switch



Don't touch luminaires when it's hot.
Ne pas touchez lorsqu'il est chaud



Select 1 > 0 > 3 > 0 > 2




Tournez le verrou de tête de rail vers l'autre extrémité du point de fixation, puis retirez les luminaires du rail comme indiqué sur le schéma.

Rotate the track head clip to the other end of the clip point and tilt the luminaires according to the drawing until the track is pulled out.

Ce projecteur sur rail est universellement compatible. Il fonctionne avec les systèmes de rail suivants :


The track light is universal compatible. It works with the following track systems:

220-250V-16A,3.7KW




1-PHASE

220-250V-16A,3.7KW




3-PHASE

220-250/400V-16A,11KW




3-PHASE


Staff




Eutrac




Global




Nuco



Nordic



Ivela



FR

Maintenance

Débranchez le luminaire avant toute opération de nettoyage. Nettoyez le luminaire avec un chiffon sec et non abrasif.

Garantie 5 années

Ce produit est garanti à compter de la date d'achat. La garantie couvre les défauts de fabrication et les dysfonctionnements dans des conditions normales d'utilisation. En cas de problème, veuillez contacter notre service client à l'adresse suivante : contact@beledpro.com

Recyclage

Ce pictogramme signifie qu'il ne faut pas jeter ce luminaire dans une poubelle ménagère. Il contient des composants qui peuvent être nocifs pour l'environnement et la santé. Veuillez consulter les informations de votre commune concernant le ramassage ou la dépose des déchets électriques.

Les données contenues dans ce manuel ne sont fournies qu'à titre d'information et peuvent être sujettes à modification, sans notification préalable. Beled se réserve le droit de modifier le produit ainsi que son manuel sans aucune restriction ou obligation de prévenir l'utilisateur. Ainsi, il est possible que le produit acheté diffère quelque peu de celui décrit au sein du présent document. La dernière version du manuel en ligne prévaut sur celle-ci. Pour l'obtenir, rendez-vous sur <https://www.beledpro.fr/fr/>

EN

Maintenance

Unplug the luminaire before cleaning. Clean the luminaire with a dry, non-abrasive cloth.

Warranty 5 Year

This product is guaranteed from the date of purchase. The warranty covers manufacturing defects and malfunctions under normal conditions of use. In the event of a problem, please contact our customer service department at the following address: contact@beledpro.com

Recycling

This pictogram means that this luminaire must not be disposed of in household waste. It contains components that may be harmful to the environment and your health. Please consult your local authority for information on collecting or disposing of electrical waste.

The data contained in this manual is provided for information purposes only and may be subject to change without prior notice. Beled reserves the right to modify the product and its manual without any restriction or obligation to notify the user. It is therefore possible that the product purchased may differ slightly from that described in this document. The latest version of the online manual takes precedence over this one. To obtain it, visit <https://www.beledpro.fr/fr/>

SP

Mantenimiento

Desenchufe la luminaria antes de limpiarla. Limpie la luminaria con un paño seco y no abrasivo.

Garantía 5 Años

Este producto tiene una garantía a partir de la fecha de compra. La garantía cubre los defectos de fabricación y los fallos de funcionamiento en condiciones normales de uso. En caso de problema, póngase en contacto con nuestro servicio de atención al cliente en la siguiente dirección: contact@beledpro.com

Reciclaje

Este pictograma significa que esta luminaria no debe tirarse a la basura doméstica. Contiene componentes que pueden ser perjudiciales para el medio ambiente y su salud. Consulte a las autoridades locales para obtener información sobre la recogida o eliminación de residuos eléctricos.

Los datos contenidos en este manual se facilitan únicamente a título informativo y pueden estar sujetos a cambios sin previo aviso. Beled se reserva el derecho de modificar el producto y su manual sin ninguna restricción ni obligación de notificarlo al usuario. Por lo tanto, es posible que el producto adquirido difiera ligeramente del descrito en este documento. La última versión del manual en línea tiene prioridad sobre ésta. Para obtenerla, visite <https://www.beledpro.fr/fr/>

NL

Onderhoud

Haal de stekker uit het stopcontact voordat u de armatuur schoonmaakt. Reinig de armatuur met een droge, niet-schurende doek.

Garantie 5 Jaar

Dit product is gegarandeerd vanaf de aankoopdatum. De garantie dekt fabricagefouten en storingen onder normale gebruiksomstandigheden. Neem in geval van een probleem contact op met onze klantenservice op het volgende adres: contact@beledpro.com

Recycling

Dit pictogram betekent dat dit armatuur niet met het huishoudelijk afval mag worden weggegooid. Het bevat onderdelen die schadelijk kunnen zijn voor het milieu en uw gezondheid. Raadpleeg uw gemeente voor informatie over het inzamelen of weggooien van elektrisch afval.

De gegevens in deze handleiding zijn uitsluitend bedoeld ter informatie en kunnen zonder voorafgaande kennisgeving worden gewijzigd. Beled behoudt zich het recht voor om het product en de handleiding te wijzigen zonder enige beperking of verplichting om de gebruiker hiervan op de hoogte te stellen. Het is daarom mogelijk dat het gekochte product enigszins afwijkt van het product dat in dit document wordt beschreven. De laatste versie van de online handleiding heeft voorrang op deze. Om deze te verkrijgen, gaat u naar <https://www.beledpro.fr/fr/>




V. 240924

Meta2 Pro Overview

Functions	Description
Light On/Off	To switch ON or OFF
Light setting	Automatically provides the best CCT and color enhancement according to commodities detected by either Auto Mode, or Take a photo in the App. Also can customize light setting in the App.
Auto Mode	To set the built-in color sensor, default "ON", and will switch "OFF" automatically once setting light with App
Energy saving setting	Not activated by default, desired brightness and waiting period can be preset
Brightness adjustment	To adjust the output brightness from 1% to 100%, default at 100%
Power Setting	To adjust the output power from 5W to maximum power of the luminaire.
Software update	To OTA (Over the Air) update the firmware (software) on the luminaires to the latest version
Group setting & Group control	To manage some luminaires in a same group and group control them ON/OFF, group light setting, and energy saving, auto mode, etc.
Settings reset	To reset the light to initial settings, and the light will be removed from APP.
Store management	To create a store or join a store

APP Download & Installation

Scan the QR code or go to ai.kaiwarez.com/#/download.
Search "Caimeta" from App Store for iOS, or Google Play Store for Android



App Compatibility

iPhone: Requires iOS 13.0 or later
iPad: Requires iPadOS 13.0 or later
iPod touch: Requires iOS 13.0 or later
Mac: Requires macOS 11.0 or later and Mac with the Apple M1 chip
Android: V4.4 or later

Languages

English and Simplified Chinese, others for customization


Status Indication & Troubleshooting

Status	Indication
Device Connecting	The light will be flashing 5 times
Device Connected Failed	APP shows Time Out
Device Connected Successes	The light will be flashing 5 times
Light changes automatically	The APP shows "Auto Mode" on

Problems	Indications Status	Solution
Connection Failures	Time Out	1, Make sure the power is on. 2, Bluetooth out of range, please move closer. 3, The Bluetooth on your smartphone or iPad is off. 4, If still not solved, please contact Kinglumi.
Mismatches	Lighting doesn't match commodity	1, Please put commodity in the center of light beam. 2, Turn "Auto Mode" on, or set light with APP. 3, Color sensor on the light doesn't work well if the commodity is too far or too small, please use APP to set the light. 4, If still not solved, please contact Kinglumi.


Sign Up and Login

- 1, Tap "Sign Up" to create your account and password
- 2, Follow the instruction to complete "Sign Up" and get into "Login" page
- 3, Use your email and password to log in



Create a Store


- 1, Create a store before adding any devices for first-time use.
- 2, Tap "About" and choose "Store Management" to create a store.
- 3, The administrator must create the store first, then invite other members to join.



Share and Join a Store


(Note: except the administrator, other members do not have the right to add and set up devices and create groups.)

- 1, For administrator, choose the store>tap "Add member">share the invitation code
- 2, To join a store: choose "Join a store">Input the invitation code and confirm.
- 3, Tap "Administrator transfer" to transfer the administrator of the store to another member.



Administrator transfer

For administrator, choose the store>tap "Administrator transfer">choose a member
Tap "Confirm", and the administrator will become a common member




Add new devices

Step 1: Tap "Add new device" or "+" on the top right of the App to view all the track lights within Bluetooth reach.


Step 2: Tap "+" on the right side of the device list, the corresponding track light will flash five times, enter a name for the track light and select a use occasion.

Step 3: Tap "Confirm", APP will show if view commodity position right now to check if the commodity is in the center of image. If "Software update" pops up, please update the software first.




Select use occasion

- 1, First-level use occasion has six categories: Groceries, Clothing & accs, Plant, Leather, Tile and Other for the commodities not belonging to the first five categories.
- 2, Groceries has sublevel use occasion: Fruit, Vegetable, Iced (seafood), Meat, and Bakery. If category not determined while setting up the light, choose "Others" at first-level use occasion first, then correct it later.
- 3, Commodity category can be changed by tapping on "Auto Mode".



View commodity position


- 1, Tap "Right now", choose your Wi-Fi and enter the password
- 2, Tap "View", will see the image of commodity, please make the commodity in the center of the image by moving light or commodity.



Software update


1. Tap "Update" on "Software update" popup box.
2. Choose your Wi-Fi and enter the password.
3. Tap "Upgrade" to update the firmware to latest version for this luminaire.

Do not leave until the updating has been finished.




Single Device Control: Settings page

- Tap settings icon on the top right corner of light icon on the Devices page to get into "Settings" page.




Light Setting

- There are three ways to set lighting.




Light Setting: Auto Mode

- 1, Auto mode is on by default. The track light senses commodity information and tune the light automatically according to a professional formula library.
- 2, Using other light setting methods, like Take photo or Customization, will turn Auto mode off. Turn "Auto Mode" on in APP if use Auto mode again.
- 3, Using Auto mode, the sensor on the light will sense commodity information every 20 minutes by default.




Light setting: Select page

- To use Take photo or Customization function, or to change brightness of luminaire, tap item "Light setting" on Settings page; or tap the luminaire icon on the Devices page.




Light Setting: Take photo

- 1, Take a photo of target commodity or choose a photo from albums.
- 2, "draw a box" or "tap" on the target colour, and the light will be changed accordingly. Usually drawing a box is suitable for large area of a colour or mixed colour, and taping is more suitable for choosing one kind of small area colour from mixed colours.
- 3, The brightness can also be adjusted by dragging the slider below.
- 4, If you are not satisfied with the light, tap "More" to have more choices.
- 5, Tap "Done" to save the setting, and "Auto Mode" will be turned off automatically.




Light Setting: Customization

- 1, Tap "Customization" on Lighting setting page. User can tune the colour, colour temperature, saturation and brightness of the light.
- 2, Tap "Done" to save the setting, and "Auto Mode" will be turned off automatically.




Light Setting: Brightness

- 1, Tap "Brightness" on Lighting setting page.
- 2, Drag the slider to adjust brightness of luminaire.




Power Setting

- 1, Tap "Power Setting" on Settings page.
- 2, Drag the slider to adjust output power of luminaire.




Energy Saving Setting

- 1, If customer(s) detected by the sensor on the light, the brightness turn to 100%.
 - 2, If no customer(s) detected, dim the light to the pre-set brightness level after a chosen time.
 - 3, Tap "Confirm" to complete the setting. Return to abandon.
- Note:** This function is off by default. To activate this function, follow the instructions below.
- **Auto-dim(min):** how many minutes after customers leave the light starts to dim. The range is from 1 minute to 60 minutes.
 - Brightness without customers: what percentage of brightness to illuminate at the standby status. The range is from 0%-100%.



Create/Delete a Group


- 1, On the Groups page, tap "+" > Input a group name and tap "confirm" to add a group.
- 2, If want to delete a group on the list. Slide left to delete it.



Group Setting


On the Groups page, tap setting icon to get into Group setting page.

- **Light On/Off:**
Turn on or off all lights in the group by APP. In order to avoid turning on or off too frequently, there is a three-second wait between On and Off.
- **Light setting:**
As the same as the single device, but this item here is for all lights in the group.
- **Energy saving setting:**
As the same as the single device, but this item here is for all lights in the group.
- **Auto Mode:**
As the same as the single device, but this item here is for all lights in the group.
- **Rename group:** Rename the group.
- **Group members:**
Show how many devices in the group. Tap to show device list.



Group members management


- 1, Tap "Group members" to get into device list.
- 2, Tap "+" to add new devices to the group.
- 3, Slide left on device list to move the device to another group or delete it from current group.
- 4, For multi operation of deleting and moving, tap "..." on the right top corner.



All devices control

Tap "Groups" icon to get into Groups page. There is an item "All devices" on the top.
Tap setting icon into All devices setting page.

- **Light On/Off:** Turn on or off all lights (including grouped and ungrouped) by APP. In order to avoid turning on/off too frequently, there is a three-second wait between On and Off.
- **Light setting:** As the same as the single device, but this item here is for all lights (including grouped and ungrouped).
- **Energy saving setting:** As the same as the single device, but this item here is for all lights (including grouped and ungrouped).
- **Auto Mode:** As the same as the single device, but this item here is for all lights (including grouped and ungrouped).



Remove a device from APP

Tap and hold on the light icon, and a dialog box pops up.

Choose "Remove" to remove the light from APP, and choose "Cancel" to abandon.

Note: Please make sure if the light can be connected with APP. If yes, please remove it with "Settings reset". If you remove the device this way, the only way you can get the device back is resetting it physically and add it back again.

- **How to reset a device physically?**
For Meta2 series, please press the physical button on the device for more than 3 seconds.

